

Cod. 208.PM01 - 208.PM02

Collegamento misuratore di energia aggiuntivo
 Additional energy meter connection
 Connexion de compteur d'énergie supplémentaire
 Conexión de medidor de energía adicional

- <https://www.emobility-scame.com>

- Download:


Manuale d'uso BE-T / BE-T User manual / Mode d'emploi BE-T / Manual de uso BE-T

Manuale d'uso BE-W[2.0] / BE-W[2.0] User manual / Mode d'emploi BE-W[2.0] / Manual de uso BE-W[2.0]


Manuale d'uso BE-R / BE-R User manual / Mode d'emploi BE-R / Manual de uso BE-R

BE-W[2.0] / BE-T

208.PM01





208.PM02



Serie BE-W[2.0] / BE-T / BE-R

BE-R




Cod. 208.PM01 - 208.PM02

CONFIGURAZIONE / CONFIGURATION / CONFIGURATION / CONFIGURACIÓN

1) Stazioni con pulsante e display
 Stations with button and display
 Stations avec bouton et affichage
 Estaciones con botón y pantalla

PRESA DISPONIBILE
 PRESA DISPONIBILE/PRESENTARE CARD
 SOCKET AVAILABLE/SHOW CARD
 PRISE DISPONIBLE/PRESENTER CARTE
 TOMA DISPONIBLE/MOSTRAR TARJETA



5s

ENERGIA FORNITA
 ???KWH
 ENERGIA FORNITA
 SUPPLIED ENERGY
 ENERGIE FOURNIE
 ENERGIA SUMINISTR.

PRESSIONE BREVE
 SHORT PRESS
 PRESSE COURTE
 PRESION CORTA

CAMBIA
 CHANGE
 CHANGEMENT
 CAMBIO

5s


PRESSIONE LUNGA
 LONG PRESS
 LONGUE PRESSION
 PRESION LARGA

CONFERMA
 CONFIRMATION
 CONFIRMACION
 CONFIRMACION

PASSWORD
 0 0
 x1
 x3
 5s ✓

OBBLIGATORIO
 MANDATORY
 OBLIGATOIRE
 OBLIGATORIO

OPZIONALE
 OPTIONAL
 OPTIONNEL
 OPCIONAL



2) Stazioni con gestione APP
 Stations with APP management
 Stations avec gestion APP / Estaciones con gestión APP
 Power management ON=tutorial APP



Numero Verde
800-018009
www.scame.com
e-mobility@scame.com

