


ART. 208.PM01 - 208.PM02

Collegamento misuratore di energia aggiuntivo
 Additional energy meter connection
 Connexion de compteur d'énergie supplémentaire
 Conexión de medidor de energía adicional

- <https://www.emobility-scame.com>
- Download: Manuale d'uso BE-T / BE-T User manual / Mode d'emploi BE-T/ Manual de uso BE-T



InfoTECH

ITALY WORLDWIDE


Numero Verde
800-018009

ScameOnLine
www.scame.com
e-mobility@scame.com

ART. 208.PM01 - 208.PM02

CONFIGURAZIONE / CONFIGURATION / CONFIGURATION / CONFIGURACIÓN

1) Stazioni con pulsante e display / Stations with button and display / Stations avec bouton et affichage / Estaciones con botón y pantalla
 Power management on= display



2) Stazioni con gestione APP / Stations with APP management / Stations avec gestion APP / Estaciones con gestión APP
 Power management ON=tutorial APP